

GLOBE VALVES - Part Number Breakdown

First set of 5 Digits in the Part Number

1st 2 Digits

01 - CRYOGENIC VALVE

3rd Digit

3 - GLOBE

4th Digit

0 - BRONZE NON-EXTENDED

1 - BRONZE EXTENDED

2 - STAINLESS BODIED EXTENDED

3 - STAINLESS BODIED NON-EXTENDED

4 - ALL STAINLESS EXTENDED

5 - ALL STAINLESS NON-EXTENDED

5th Digit

1 - WELD OR BRAZE CONNECTION

2 - ANGLED VALVE

3

4

5 - THREADED

Second set of 4 Digits in the Part Number

1st and 2nd Digits

THREADED

0400 - 1/2"

0600 - 3/4"

1000 - 1"

1400 - 1.1/2"

2000 - 2"

WELDED

15 - 1/2"

20 - 3/4"

25 - 1"

40 - 1.1/2"

50 - 2"

65 - 2.1/2"

80 - 3"

3rd and 4th Digits

COPPER

15 = 5/8"

-

28 = 1 1/8"

42 = 1 5/8"

-

-

-

STAINLESS

21

26

33

48

60

73

88

SW OR BW SIZE 21 = 21.3 MM SW, BW OR STUBBED VALVE I.E. 1521

SBT OR COPPER STUBBED SIZE I.E. 28 = 1.1/8" SBT SIZE I.E. 2528

Third set of 4 Digits in the Part Number

1st Digit

0 - STANDARD VALVE

5 - NORMALLY GLOBE CHECK VALVES

7 - SPECIFIC USER REFERENCE

2nd Digit

0 - STANDARD VALVE

5 - GLOBE CHECK OPTION

9 BRONZE INTERNALS

3rd Digit

0 NON-EXTENDED

1 270MM (10 5/8") EXTENDED

2 370MM (14 1/2") EXTENDED

3 450MM EXTENDED

6 600MM EXTENDED

4th Digit

0 - BRONZE SOCKET WELD

1 - BUTT WELD OR BSPP

2

3

4 - SOCKET WELD

5

6 - NPT

7 - STAINLESS STUBBED

8 - COPPER STUBBED